


Instruction Manual



Enjoy PriY1q *S u U h

Diagram



(D G-Spot Stimulation

(!) ++-Key

@---Key

@ U-Spot Stimulation

⊖ On-OffKey

⊕ Gold Plating Handle

Directions for use

Preu key® for more than 3 seconds to turn it on.

When the signal light is on, it is the standby state.

Press key(Q) to switch vibration frequency. 10 Frequencies switch in turn.

PressKey(Dforinversionswitching.

In any state of WORKing, Press key (!) for more than 3 seconds to turn it off.

Rechargeable Description

This unit is green eco-friendly charge design with use universal charging interface.

Any USB device can be charging.

The signal light flashes continuously that is the correct charging.

When the charging is finished, the light will stop flashing.

If the light is not on during charging, please check if the charging circuit is obstructed.

Notice:

No one is allowed to use this unit during charging.

Please use this unit in concert with the water-soluble lubricant according to the actual situation.

Do not use the corrosive detergent or disinfectant to clean this unit.

For your health, please do not share this unit with other people.

Minors are prohibited to use this unit.

Gebrauchsanweisung

Drücke die Einschalttaste (Zwischen + und -) für ca. 3 Sekunden, bis eine LED aufleuchtet – das Gerät ist aktiviert
Drücke + bzw. – Taste um, die gewünschte Funktion bzw. Intensität einzustellen.

Zum Ausschalten erneut die Einschalttaste länger drücken, bis LED erlischt.

Wiederaufladen

Mittels mitgeliefertes USB Adapterkabels kann das Gerät wieder aufgeladen werden.

Das Signallicht blinkt kontinuierlich – das Gerät wird aufgeladen

Erlischt das Signallicht – das Gerät ist geladen.

Achtung!

Das Gerät darf niemals während des Ladevorgangs benutzt werden!

Bitte lassen Sie das Gerät während des Ladevorgangs nicht unbeaufsichtigt!

Reinigungshinweise

- Bitte keine korrosive (reibende) Stoffe für die Reinigung verwenden!
- Das Gehäuse ist Spritzwassergeschützt jedoch nicht wasserdicht, das Gerät darf nicht ins Wasser getaucht werden.
- Nach jeder Verwendung empfehlen wir das Gerät zu desinfizieren.
 - Bitte geben Sie das gerät nach dem Gebrauch nicht an andere Personen weiter!